

Power of DraftSight







Power of DraftSight

DraftSight, brought to you by Dassault Systèmes, the 3DEXPERIENCE company, has been trusted by millions of users worldwide. DraftSight provides a familiar, intuitive 2D drafting experience with options for advanced productivity tools, 3D design capabilities, parametric constraints, and flexible licensing options including perpetual licenses and network licenses for organizations with multiple users or sites.

Power of DraftSight is a guide to make the most of DraftSight tools and productivity features. DraftSight offers multiple product options with differing levels of functionality. To see which features are available in each, visit <u>DraftSight.com</u> or see our <u>Feature Matrix</u>.

Table of Contents

PowerTrim1
Dimension Tools
Mechanical Toolbox4
Toolbox Layers
Mouse Gestures
3D ContentCentral
3D Modeling9
Parametric Constraints
Draw Compare 11
Drawing Standards
Customize with API's14
Design Resources15
Associative Patterns
Additional Resources



PowerTrim

Save time by using the PowerTrim command to efficiently edit your geometry.

Found only in DraftSight, the **PowerTrim** tool allows you to quickly and accurately trim multiple entities by simply dragging your pointer across them.

Since **PowerTrim** automatically considers everything in your drawing to be a cutting plane, you can save time and lessen your frustration by not having to identify and select those entities individually.



You can even change the behavior of **PowerTrim** to make it **Extend** entities in the same manner, simply by holding down the shift on your keyboard.

PowerTrim is found in the **Modify** panel of the Ribbon's **Home** tab.

By selecting individual entities, you can also use **PowerTrim** to extend or shorten them along their current paths, or let it do the work of finding and extending to an inferred intersection point.





Dimension Tools

Increase your productivity by utilizing time-saving dimension tools.

In addition to the traditional individual dimensioning commands, DraftSight adds two powerful tools that can save you time by automating your tasks. Both can be found in the **Dimensions** panel of the **Annotate** tab.

The Smart Dimension tool inserts the proper type of Dimension by detecting the type of entity you select.



By using **Smart Dimension**, you no longer have to stop your command and select a new one just to use a different type of **Dimension**. In our example, the **Linear, Aligned, Radial** and **Angular Dimensions** were all made by running the **Smart Dimension** tool once.





In many cases, the **Auto Dimension** tool can eliminate the extra work of adding dimensions to your design.

Drafting and Annotation 🔽 📮 🖻	3 € 5 • C • =		DraftSigl	nt Premium - NONAME_0.dwg
Home Insert Import Export Atta	ch Annotate Sheet Constraints Manage View	Powertools Mechanical		
A Standard T T 0.2 Find Text Check Spelling	Auto Dimension Auto	Create	Cloud Mask	Ĥ+ Annotation Scaling →
Text	Dimensions	C Append to	Markup	Annotation Scaling
NONAME_0.dwg × +	Auto Dimension	¢ [] Remove from		
	Creates dimensions automatically: AUTODIMENSION	🕞 Update		

Auto Dimensioning is a two-step process. First, you must create a **Bounding Box** which is also found in the **Dimensions** panel.

Then you select the entities within the **Bounding Box** that you want to dimension. You can set various options in the **Auto Dimension** palette, preview and apply the **Dimensions** when you're satisfied with the result.





Mechanical Toolbox

Tap into the power of the mechanical toolbox to create designs faster and with more accuracy.

DraftSight contains robust mechanical tools and symbols that will help you standardize your mechanical drafting needs. You don't need to purchase a third-party program add-on, or worse, different CAD software, as this industry-proven suite of tools is built right in.

Drafting	Drafting and Annotation 🗸 📑 🖶 🖶 🗢 🤸 🗸 🗸													DraftSight Premium - NONAME_0.dwg				
Home	Insert	Import	Export	Attach	Annotate	Sheet	Constr	raints	Manage	View	Powertoo	Mechan	ical					
Standards	To Settings	Insert	👕 🖡 Edit	T+	Edit	Hit Insert	۲ Edit	•	∽ ¥⊇ ⊉) Insert	0 Edit	Edit	Insert Table		Insert	6 Edit		
Manag	je	Hard	ware	Screw Co	nnections	H	Holes		Symbols	Ball	oon	BOM	Revision	n Table	Fram	ne		
NONAME	_0.dwg	×	+															

The **Mechanical Toolbox** allows you to choose which industry standard you want to use (or create your own custom standard).

Continue your design by accessing your symbols from the extensive library included in the **Toolbox**. Choose hardware such as bolts, nuts, and washers, or from various screw and hole configurations.

Finally, DraftSight can automate the task of creating and tracking a bill of materials, and even help with tracking your drawing revisions.

Toolbox - Standarda	×	Toolbox - Hardware	×
Active stands fs AKE Inch Basic standards ANS Inch ANS Inch ANS Metric BIN DIN ISO ISO ISO	Activate	Active standard: Active	14 10
Custom standards	Copy	Washers Properties	
	Delete	Creation method Near side	
	Ell Rename	Head options Cross 🗸	
	Edit	Thread display Simplified	
	🖙 Activate	Fastener length 0.125	
	Export	Thread length 0.125	
No active standard	Close 2 Help	Settings	telp



Toolbox Layers

Maintain your drafting standards by setting the layer for the type of entity.

The **Toolbox Layer Settings** feature allows you set which layer a specific entity is placed upon. It helps you maintain your layering standard and removes the need to change the active layer prior to adding different entities.

You can access the **Layer Settings** from the **Manage** panel of the **Mechanical** tab in the ribbon.

1	Draftin	g and Annot	ation	~ [+	📥 💾 é	🖻 🕇 🔻 🕯	c • •								Dra	aftSight P	remium	n - NONAME_0.dv	vg
	Home	e Insert	Import	Export	Attach	Annotate	Sheet	Const	raints	Manage	View	Powerto	ools Mechanic	cal					
	🖌 Standards	To Settings	Insert	T i Edit	+	edit	내 Insert	Edit	♣	S Store) Insert	o Edit	Edit	Insert Table	1000 € 1000 € 1000 € 1000 € 1000	Insert	Edit		
	Mana	ige	Hard	ware	Screw Co	nnections	ł	Holes		Symbols	Ball	oon	BOM	Revision	Table	Fra	me		
	% Settings Customizes	 Toolbox setti	ings: TB_SE	TTINGS															

By default, it uses its own set of layers (prefixed with TB_), but you can also access your own layers that are in the drawing. In addition to the **Mechanical Toolbox** specific entities, you can also assign a layer to any other standard entity that DraftSight creates, which makes **Toolbox Layers** a valuable tool even if you don't need the other **Mechanical Toolbox** functions.

Mapping your layer settings is easy. From the **Toolbox Settings** dialog, simply find the entity type you want to use, then select the **Layer** it will be placed on from the pulldown. Should you choose, you can also specify the **LineColor, LineStyle**, or **LineWeight** as well.

Make sure the **Enable Predefined Layering** box is checked, and you'll no longer have to worry about changing your active layer whenever you draw those types of entities.

Active standard:	ANSI Inch				
DraftSight Entities	Toolbox Entities	Layers			
Entity Type 🔺 3DFace	Layer Name <active></active>	LineColor O ByLayer	LineStyle ByLayer Solid line	LineWeight ^ — ByLayer	6
3DSolid	<active></active>	O ByLayer	ByLayer Solid line	— ByLayer	2
Arc	<active></active>	O ByLayer	ByLayer Solid line	- ByLayer	
Attribute	<active></active>	O ByLayer	ByLayer Solid line	ByLayer	
Block	<active></active>	O ByLayer	ByLayer Solid line	ByLayer	
Centerline	<active></active>	O ByLayer	ByLayer Solid line	ByLayer	
Centermark	<active></active>	O ByLayer	ByLayer Solid line	ByLayer	
Circle	<active></active>	O ByLayer	ByLayer Solid line	ByLayer	
Cloud	<active></active>	O ByLayer	ByLayer Solid line	- ByLayer	
Dimension	Dimensions 🗸	O ByLayer	ByLayer Solid line	— ByLayer	
Ellipse	<active></active>	O ByLayer	ByLayer Solid line	— ByLayer	
EmbeddedOb	TB_BOM	O ByLayer	ByLayer Solid line	— ByLayer	
Hatch	TB_Center TB_Dimensions	O ByLayer	ByLayer Solid line	- ByLayer	
Image	TB_Frame	O ByLayer	ByLayer Solid line	— ByLayer	
Infiniteline	TB_Hidden TB_Hole table	O ByLayer	ByLayer Solid line	— ByLayer	
Leader	TB_Revision table	O ByLayer	ByLayer Solid line	— ByLayer	
Line	Actions	O Pulavor	Pulaver Colid line	Pul suge	



Mouse Gestures

Increase your productivity by accessing your most frequently used commands with mouse gestures.

Mouse Gestures provide a fast and convenient way to speed up your drafting technique, saving you time and increasing your efficiency and productivity.

When it's enabled, you can access various commands by simply holding down the right mouse button and moving the mouse in the proper direction. The gestures are easy to set up. You can access them from the **Customization** panel of the **Manage** tab.

Drafting Home	g and Annotat Insert	tion 🔽 Import Exp	🗅 📑 📑	ch Anno	▼ C ▼ = otate Sheet	Constra	ints Mana	ige Vie	w Powert	ools Mechanical		DraftSig	ht Premium - NONAME_0.dwg
Drawing Standards	Verify Standards	Interface	Options	Mouse Gestures	Load Application.	Run . Script	Add-Ins		Smart Calculator	Units Clean	Record	Stop	
Stand	lards	C	ustomization	ı	4	pplication	5	U	tilities	Drawing	Ma	cro	
NONAM	E_0.dwg	0 Mouse	Gestures										
		Customize	s mouse ges	tures: GEST	URE								

DraftSight allows either four gestures, which correlate to moving the mouse forward, back, left, or right, or eight gestures, which add the diagonal directions. This example shows default values, which you may like, but setting up your own most frequently used can significantly increase your speed and production.

				General
Category: All Commo Mouse Gesture as Search for:	ands signed o	commands	e mouse gestures Gestures Gestures Print list	Category: Mouse G Search for:
Category ^	Icon	Command	Select ⊕+	Catego
File	1	Open	+8	Draw
File		Save	+8	File
View	Ø	Zoom Bounds	18	File
				Modify Modify Modify View

All Commi	ands signed o	commands	e mouse gestu Gestures	
earch for:			Gestures	
		Reset to Defaults	Print lis	
Category ^	Icon	Command	Select	
Draw	B.	SimpleNote	8.	
File	1	Open	+8	
File	B	Save	+8	
Modify	1	Сору	*8	
Modify	2	Offset	×8	
Modify	al.	Trim	8.	
View	ø	Zoom Bounds	18	
Description				



×

Simply uncheck the currently assigned commands, then search for the command you want. Once found, use the **Gesture Selection** Pulldown to choose your direction. In our example, we're changing the default down gesture from Save to PowerTrim.

Mouse Ges	tures			×	Mouse Gestur	es			1
General					General				
Category: All Co	mmands	~	Enable	mouse gestures	Category: All Comm	ands	~	Enable	mouse gestures
Mouse Gestun	e assigned	commands	4	Gestures	Mouse Gesture as	signed	commands	. 40	Sestures
Search or: Pow	er Trim		08	Gestures	Search for:			O 8 Gestures	
	_		Reset to Defaults	Print list				Reset to Defaults	Printlist
Category Modify	▲ Icon	Comm Power Trim	and	Select	Category A	Icon	Comm	and	Select
,				None	File	1	Open		+ 8
				-0-	Modify	SF	Power Trim		+8
				8+	View	Ø	Zoom Bounds		18
Decomption									
Trim or extends m	ultiple entit	ies by dragging the poin	ter across them: PO\	VERTRIM					

When you execute a Gesture, DraftSight will display a Gestures Navigation Guide when you keep the right button depressed. It will show you which command you are about to begin. You can release the mouse button to accept it, move the cursor over the icon, or even choose a different command to execute.







3D ContentCentral

Access free content from the integrated 3D ContentCentral palette.

DraftSight lets you easily search for and automatically download both user contributed and supplier-certified 2D parts & assemblies, 2D blocks, library features and macros.

After creating your free account and logging in, simply enter your search term, and the **3D ContentCentral** palette will display all the matches from its huge library of content.

In our example, we've searched for "Chair", and quickly found a **block** to use in our design.



Simply drag and drop the block into your DraftSight drawing, and set the scale, rotation, and its location.

By joining millions of other CAD users in the **3D ContentCentral** community, your access to the blocks, parts, or models you need has never been easier.





3D Modeling

Take your designs to a new dimension with all the 3D tools you need.

DraftSight Premium and DraftSight Enterprise Plus include the **3D Modeling Workspace**, where you can access the full suite of powerful 3D modeling and editing tools.



Create **3D solids**, such as **Boxes, Cones, Cylinders**, and **Spheres**. Make **Faces** and **Meshes** or transform 2D shapes into **3D solids** to use for 3D printing, laser cutting, or in other Dassault Systèmes solutions and services.

The **3D Modeling Workspace** also contains a feature rich set of editing tools, which will allow you to create complex shapes from your 3D primitives.

Navigating your 3D model has never been easier. Choose from pre-configured orthographic or isometric views or view your design from any direction you want with the various **Orbit** commands.

Finally, display your model however you like with display options such as **3D Wireframe**, **Hidden**, **Flat with Edges** or **Gouraud**. Or use DraftSight Premium's powerful **Animated Rendering** tool to see how it will look after construction or manufacturing.



9



Parametric Constraints

Ensure your design intent by utilizing the power of 2D parametric constraints.

DraftSight Premium and DraftSight Enterprise Plus allow you to apply both **Geometric** and **Dimensional Constraints** to your design.

Constraints can make sure certain entity relationships are maintained during and after the design phase. Typically, **Geometric Constraints** are applied first. You might want to make sure certain elements are always **Parallel, Perpendicular** or **Concentric**.

Once your geometry is properly constrained, you can apply **Dimensional Constraints**, such as **Linear, Radial** or **Aligned** distances.

DraftSight's **Constraint** tools are easily accessed from the **Ribbon**. From here, you can control their icon's visibility, which **Constraints** you want to use, or even define your own **Constraint Parameters**.

Aa	Drafting and A	nnotat	ion	~ C+ I	📥 💾 é	∋ 🕇 -	1 T F 🖌						DraftSight Premium - NONAME_0.dwg
	Home Inse	ert	Import	Export	Attach	Annotate	Sher:	Constraints	Manage	View	Powertools	Mechanical	
₽ *//> Ø	Image: marked black Image: marked black Ima		Linear	Aligned	2) 22 23 24 24 24 24 24 24 24 24 24 24 24 24 24		X Dete	ons Parameters					
	Geometric			Dimen	sional		Ma	inage					
	NONAME_0.dwg	1	×	+									

In the example, the design has been constrained with **Parallel, Concentric,** and **Tangent Constraints**. Attempting to move the circle will also move the entities constrained to it. Attempting to stretch the bottom line affects all the others as well.





Draw Compare

Compare drawing revisions to quickly identify and track changes.

The **Draw Compare** tool allows you to quickly identify the differences between two drawing files. You can find it in the **Powertools** tab of the **Ribbon**.



Draw Compare will graphically depict anything from the first drawing that's not in the second in blue, and anything not in the second in green.

You can customize the colors to match your preferences, and you can also instruct it to show only entities that have been added, or only those that have been removed.

Should you need to refer to them later, you can even save an image file of the differences.





Drawing Standards

Audit and fix non-compliant entities with the drawing standards tool.

DraftSight makes it easy to ensure your company or department CAD Standards. The first step is to create a drawing that has all your proper **Layers, Linetype, Text**, and **Dimension Styles**. Save it as a **Drawing Standards** file (.dws).

Next, apply your **Standards File** to your drawing. You can find the interface from the **Standards** panel of the **Manage** tab in the **Ribbon**.



Add one or more .dws files. Depending on your environment, you may want to have a separate file for each discipline. The order of the files in the configuration manager determines the priority.

Other options include the ability to choose which categories will be checked, and how to handle notifying the user of standards violations.





Standards verification can be either an active or passive process. If you've disabled **Alert Messages**, you'll need to run the **Verify Standards** tool to check the drawing. You can find it next to the **Drawing Standards** tool in the **Ribbon**.

Draftin Home	g and Annotat e Insert	tion 🔽 Import Exi	Di 📥 🗄	d 🖶 🕤	▼ C ▼ ∓	Constra	ints Mana	ae Vie	w Powert	ools Mechanica	Į	DraftSig	ht Premium - NONAME_0.dwg
Drawing	L) Verify		¢,	€Ó Mouro	•	II ➡ Ruo			+- ×∎		Pacard	Stop	
Standards Stand	Standards	C	ustomization	Gestures	Application	Script	Add-Ins	- U	Calculator	Drawing	Ma	cro	
Checks the	t andards current drawin	g for standard	s violations:	VERIFYSTAN	IDARDS								

If you choose to notify the user with a popup message, any time a violation is encountered, a message box will appear, giving the user the chance to continue with the verification, where they can either fix or ignore the violation.





Customize with API's

Extend the power of DraftSight by automating tasks through various API's.

DraftSight makes it easy to load and use your favorite AutoLISP® or Visual LISP® code to automate tedious or repetitive tasks. Use the **Load Application** interface found in the **Manage** tab of the **Ribbon**.

In addition to LISP based files, you can also load Dynamic Link Libraries (.dll files) that might have been created in the C# language.

Dra	fting and Annotat	ion 🗸	C: 🖻 🗄) 🖨 🕤	• C • =							DraftSig	ht Premium - NONAME_0.dwg
Н	ome Insert	Import Ex	port Atta	ch Anno	otate Sheet	Constrai	nts Man	age Vie	w Powert	ools Mechanical			
	₽ Ĵ	•	۰.	÷Ó	۲		ĎŸ+		+- ×	•	•		
Drawing Standards	Verify Standards	Interface	Options	Mouse Gestures	Load Application	Run Script	Add-Ins	Inquiry •	Smart Calculator	Units Clean *	Record	Stop	
Standards Customization			A	Applications Utili				Drawing	Ma	Macro			
NOM	NON 🕟 Load Application						M_ † Ad	d-Ins					
	Loads application	ons for use in	the program	: LOADAPP	LICATION								

Once loaded, you have the option to have them load every time you open a drawing by checking the **Start Up** option in the **Add-Ins interface**.

If you're not well versed in the external API's DraftSight uses, you can still easily automate repetitive tasks with the powerful **Macro Recorder** feature. Also found in the **Manage** tab, just click on the **Record** tool when you're ready. Perform whatever commands you want to repeat, then simply **Stop** the recording. Play back the **Macro** whenever you need to reproduce your drawing tasks.

Draftin	ng and Annotat	ion 🗸	C; 📩 🗄	8 5	• 🕂 • •							DraftSi	ight Premium - NONAME_0.dwg
Hom	e Insert	Import Exp	port ∧tta	ch Anno	tate Sheet	Constrain	its Mana	ige Vie	w Powert	tools Mechar	ical		
Drawing	D Venty	Interface	¢, Options	50 Mouse	Load	∎ ⇒ Run	Add-Ins		×∎ Smart	Units Clea	Kecon	d Stop	
Standards Stan	dards	Ci	ustomization	Gestures	Application Ap	oplications		- 0	tilities	Drawing		/lacro	
NONAM	4E_0.dwg	\times +									🔴 R	ecord	





Design Resources

Quickly access and re-use design elements from other drawings with the design resources palette.

Save time and effort by accessing content that's already been created by using DraftSight's powerful **Design Resources Palette**.

With **Design Resources**, you can navigate to any accessible file to find your desired content, or simply look through any files you may have currently open.

Just highlight the file you want to access, and you'll be able to easily import **Blocks, Layers, Styles, Sheets**, or even **Reference Files** from that file.

Right click on the item in the **Content Pane** to add it to your current drawing, or just drag and drop. Whichever method you choose, DraftSight makes it easy to quickly find the resources you need.





Associative Patterns

Take control of the repeatable geometry in your design with associative patterns.

The **Associative Pattern** tool groups the entities within your **Patterns**, allowing you to easily edit their spacing, relative location, and size using **Pattern** specific **EntityGrips**. The **Associative Pattern** tool is found in the **Modify** panel of the **Ribbon's** home tab.



The dialog box will guide you through your object selection and **Pattern Settings**. In addition to **Linear** style **Patterns**, you can also make them **Circular**, or along a defined **Path**. You can even add levels to define your **Pattern** in 3D.

Pattern X	Attern X	ma Pattern
Circul: Linear Puth	Circular inear Path	Circular in ar Path
Specify entities No entities No entities No entities No entities No entities No entities specified.	Specify entities L entity specified.	Sectorily entities Control of the sector of
Settings	Settings	Settings
Associative Number of elements on: Spacing between elements on: Vertical axis: 4 Vertical axis: 1.0000	Associative Cicodoxise Base pattern on: Angle Between and Tatal Number of Elements on	Base pattern on: Distance Between and Total Number of Elements
Horizontal axis: 1.0000	Fill angle: 360	Total number: 6 Element base point Rows
Levels: 1 😨 Levels: 1.0000	Total number: 4 Levels: 1 🗘 Spacing on levels: 1.0000	Use last entity selected Count: 1 +
Element base point	Rows: 1 Spacing on Rows: 7.6956	Y: 0.000
X: 0.0000	Use last entity selected	Align elements with path
Y: 10,0000	X: 0.0000 X: 0.0000 X2	Specify tangent direction
	Orient elementa about axia	Angle: 0
Prevew	Prevew	Preview CK X Cancel C Help



Once created, edit your **Associative Pattern** with its special **EntityGrips**. Using these grips, you can dynamically change the row and column counts, change either one's spacing, or just move the entire **Pattern**.

Simply click the **EGrip** you want to use and pull your mouse in the direction to change. You'll see a preview of any rows or columns added based on your new location, or any change in spacing – depending on which **EGrip** you choose.



Additional Resources



DraftSight Support https://www.draftsight.com/support/home

DraftSight Community https://www.draftsight.com/community

Follow us



YouTube

Our 3DEXPERIENCE® platform powers our brand applications, serving 11 industries, and provides a rich portfolio of industry solution experiences.

Dassault Systèmes, the **3DEXPERIENCE** Company, is a catalyst for human progress. We provide business and people with collaborative virtual environments to imagine sustainable innovations. By creating 'virtual experience twins' of the real world with our **3DEXPERIENCE** platform and applications, our customers push the boundaries of innovation, learning and production.

Dassault Systèmes' 20,000 employees are bringing value to more than 270,000 customers of all sizes, in all industries, in more than 140 countries. For more information, visit www.3ds.com



Europe/Middle East/Africa Dassault Systèmes

10, rue Marcel Dassault CS 40501 78946 Vélizy-Villacoublay Cedex France

Asia-Pacific Dassault Systèmes K.K. ThinkPark Tower 2-1-1 Osaki, Shinagawa-ku, Tokyo 141-6020 Japan

Americas Dassault Systèmes 175 Wyman Street Waltham, Massachusetts 02451-1223 LISA

